

BE
User Manual

- 1 Seat Height**
Lift the right front lever. Sit down to lower the seat or remove your weight to raise it. Release the lever to lock.
- 2 Seat Depth**
While seated, lift the left lever and slide the seat to the desired position. Release the lever to lock.
- 3 Tilt Preference Selector**
Select the degree of recline movement for your preference and your task. Sit fully upright. Rotate the back right lever until it clicks into one of three positions—all the way back for the most movement, in the middle for less, or all the way forward for greater upright support.
- 4 Flex Top**
Simply rest your arms comfortably over the top of the Flex Back[®] of seat edge flex.
- 5 Flex Seat**
Sit in any position—forward, sideways or perched—and the Flex Seat supports you with 270° of seat edge flex.
- 6 Dynamic Suspension Control**
The synchronized recline counterbalances your body weight for a smooth and effortless ride. Four independent flexors act as suspension devices that respond to your multi directional movements—forward, backward and side-to-side.
- 7 Additional Lumbar Support**
Sit back and the additional lumbar supports you and responds to your multidimensional movements.